



ELECTROSWITCH
SWITCHES AND RELAYS

CROSS REFERENCE LIST

GE Series SB1 to Electroswitch Series 24

Use this cross reference list to identify the correct Electroswitch Series 24 switch to replace a GE SB1 Series switch. Don't see your GE Series switch in the list – contact Electroswitch for additional cross reference information.

Key: **Bolded** Model Number Indicates Switch is In Stock.

* Indicates Model Number is for Breaker Control Switch.

† Indicates Model Number is for Breaker Control Switch with Pull-to-Lock.

SB1	Series 24	SB1	Series 24	SB1	Series 24
16SB1A1	2428D	16SB1CA24	2415C	16SB1CG7	24204B
16SB1AA1	2427D	16SB1CA25	2414C	16SB1CG8	74204B
16SB1B1	2440D	16SB1CA26	2423E	16SB1CG9	24205B
16SB1B2	2443D	16SB1CB5	2426	16SB1CG10	74205B
16SB1B3	2436D	16SB1CB12	2418C	16SB1CG11	24206B
16SB1B4	2437D*	16SB1CB13	2419C	16SB1CG12	74206B
16SB1B6	2441D*	16SB1CB14	2420C	16SB1CG13	24201B-002
16SB1B7	2439D*	16SB1CB15	2425	16SB1CG14	74201B-010
16SB1B9	2442D*	16SB1CE25	2407C	16SB1CG15	24201B-002
16SB1B10	2445D*	16SB1CE27	2402C	16SB1CG16	74202B
16SB1B11	2438D*	16SB1CE28	2430C	16SB1CG17	24202B-002
16SB1B14	2444D*	16SB1CE29	2434C	16SB1CG18	74203B
16SB1B15	2446D*	16SB1CE33	2431C	16SB1CG19	24202B-002
16SB1B16	2447D*	16SB1CE52	2433E	16SB1CG20	74204B
16SB1B17	2448D*	16SB1CE55	2435E	16SB1CG21	24203B-002
16SB1B18	2449D*	16SB1CE57	2432E	16SB1CG22	74205B
16SB1B19	2450D †	16SB1CE61	2433C	16SB1CG23	24203B-002
16SB1B20	2451D*	16SB1CE62	2432C	16SB1CG24	74206B
16SB1B21	2452D †	16SB1CE63	2435C	16SB1CG25	24201B
16SB1B22	2453D*	16SB1CF6	2423C	16SB1CG26	24201B
16SB1B23	2453D*	16SB1CF7	2418E	16SB1CG27	24202B
16SB1B24	2454D*	16SB1CF8	2419E	16SB1CG28	24202B
16SB1B25	2455D†	16SB1CF9	2424E	16SB1CG29	24203B
16SB1B26	2456D*	16SB1CF11	2404C	16SB1CG30	24203B
16SB1CA1	2401C	16SB1CF16	2405C	16SB1CG31	24204B
16SB1CA7	2411C	16SB1CF17	2413C	16SB1CG32	24001B
16SB1CA8	2422C	16SB1CF22	2403C	16SB1CG33	24001B
16SB1CA15	2412C	16SB1CF23	2406C	16SB1CG34	24001B
16SB1CA18	2409C	16SB1CG1	24201B	16SB1CG35	24001B
16SB1CA19	2410C	16SB1CG2	74201B	16SB1CG36	24001B
16SB1CA20	2408C	16SB1CG3	24202B	16SB1CG37	24302YD
16SB1CA21	2417C	16SB1CG4	74202B	16SB1CG40	24002B
16SB1CA22	2422E	16SB1CG5	24203B	16SB1CG41	24002B
16SB1CA23	2416C	16SB1CG6	74203B	16SB1CG42	24304YD

Note: Many SB1 switches have the suffix “-Xn” to denote panel thickness. The “n” signifies the number of sixteenth of an inch of panel thickness [eg: -X2 equals 1/8"]. The Series 24 switches listed above fit panels up to 3/16". Contact factory for thicker panels.



ELECTROSWITCH
180 King Ave. • Weymouth, MA 02188
Tel. 781.335.5200 • Fax. 781.335.4253
www.electroswitch.com
info@electroswitch.com



ELECTROSWITCH
SWITCHES AND RELAYS

CROSS REFERENCE LIST

GE Series SBM to Electros witch Series 24

Use this cross reference list to identify the correct Electros witch Series 24 switch to replace a GE SBM Series switch. Don't see your GE Series switch in the list – contact Electros witch for additional cross reference information.

Key: **Bolded** Model Number Indicates Switch is In Stock.
* Indicates Model Number is for Breaker Control Switch.
† Indicates Model Number is for Breaker Control Switch with Pull-to-Lock.

SBM	Series 24	SBM	Series 24	SBM	Series 24
10AA001	2401C	10AA033	24204B	10AA064	24304YD
10AA002	2402C	10AA034	74204B	10AA065	2427D
10AA003	2403C	10AA035	24205B	10AA066	2428D
10AA004	2404C	10AA036	74205B	10AA067	2429D
10AA005	24302YB	10AA037	24206B	10AA068	24202B-002
10AA006	2405C	10AA038	74206B	10AA100	2440D*
10AA007	2406C	10AA039	24201B-002	10AA101	2443D*
10AA008	2409C	10AA040	74201B-010	10AA102	2436D*
10AA009	2410C	10AA041	24201B-002	10AA103	2437D*
10AA010	2411C	10AA042	74201B-010	10AA104	2441D*
10AA011	2407C	10AA043	74202B-010	10AA105	2439D*
10AA012	2408C	10AA044	24202B-002	10AA106	2442D*
10AA013	2412C	10AA045	74202B-010	10AA107	2438D*
10AA014	2417C	10AA046	24203B-002	10AA108	2444D*
10AA015	2416C	10AA047	74203B-010	10AA109	2446D*
10AA016	2415C	10AA048	24203B-002	10AA110	2445D*
10AA017	2414C	10AA049	74203B-010	10AA111	2448D*
10AA018	2418C	10AA050	24201B	10AA112	2447D*
10AA019	2419C	10AA051	24201B	10AA113	2449D*
10AA020	2420C	10AA052	24202B	10AA114	2450D†
10AA021	2422C	10AA053	24202B	10AA115	2451D*
10AA022	2423C	10AA054	24203B	10AA116	74205WL
10AA024	2424E	10AA055	24203B	10AA117	2452D†
10AA025	2426	10AA056	24204B	10AA118	2453D*
10AA026	2425	10AA057	24001B	10AA119	2453D*
10AA027	24201B	10AA058	24001B	10AA120	74206SH†
10AA028	74201B	10AA059	24001B	10AA121	74205WK†
10AA029	24202B	10AA060	24001B	10AA122	2454D*
10AA030	74202B	10AA061	24001B	10AA123	2455D*
10AA031	24203B	10AA062	24302YD	10AA124	74206SH†
10AA032	74203B	10AA063	24002B		



ELECTROSWITCH
180 King Ave. • Weymouth, MA 02188
Tel. 781.335.5200 • Fax. 781.335.4253
www.electros witch.com
info@electros witch.com